

ENERGIA ON

Outlet oxygen concentration detector

Instruction:

- 1, Adopt 3 years imported long-life electrochemical oxygen sensors.
- 2, This tester needs to correct before use, please check the correction instruction;
- 3, Please replace the battery if it's low, or the numerical value will show incorrectly;
- 4, This device will auto shut down after turning on for 30 mins.



Correction instruction:

- 1, Turn on the device, connect the pipette filler with the tester and pinch for 2-3 times to suck the fresh air; 3 mins later, if the numerical value is not within 20.9 ± 0.5 , then the tester needs to correct.
- 2, Turn on the tester, simultaneously press "Key 1" and "Key 2" for 5 seconds, then loosen the keys and enters the correction function.
- 3, Correction: press "Key 1" to increase 0.1%, press "Key 2" to decrease 0.1%, until correct to 20.9 ± 0.05 , then shortly press the left key to exit. Then it's in test condition.

